

V105 DIP SWITCH / FUNCTIONS / DB PIN NUMBERS

DB25 PIN #	FUNCTION	DIP SW #	
4	RTS	1	Ser
20	DTR	2	Ser
7	GND Serial	3	Ser
none	Pad on Pcb	4	
4	D2	5	Par
5	D3	6	Par
25	GND Parallel	7	Par
3	D1	8	Glv
2	D0	9	Glv
none	Pad on Pcb	10	

If using glove need to use parallel interface

PC3D PIN NUMBERS / FUNCTIONS

DB25 Pin #	Name	Function
4	RTS	Glasses Control Low = Right active (dark)
20	DTR	Power +
7	GND Serial	GND

Note: RS232 Levels must be at least $\pm 10V$